

PVC BACKED COIR MATTING FITTING GUIDE

EVERYTHING YOU NEED TO KNOW



PVC BACKED COIR MATTING

Our PVC Backed Coir matting is easy to trim in situ. If you have an irregular shaped mat well (e.g. without 90 degree angles) simply order a size that will cover the full surface area and then trim the matting in situ by following our useful guide. You will need a sharp "Stanley" type craft knife, a straight edge to cut against and a piece of white chalk.

Call our expert team
on 020 8819 5869 with
any queries

FITTING PROCESS:

- Firstly lay the mat face up in the mat well (rubber backing side down).
- Now lift up the edges one by one and run the chalk along the edge or rim of the mat-well coating it with the chalk.
- Let the mat drop onto the chalked edges to mark the rubber backing.
- Take the mat out of the well, turn it over and using the knife and straight edge cut about 2mm inside the chalk mark on all 4 sides, you really only need to score the backing and tear the waste piece off.
- The mat should drop back in to the well. Extra trimming in places may be required for a snug fit.

FEATURES

- A WIDE CHOICE OF GRADES, THICKNESSES AND COLOURS
- CUT TO SIZE TO THE NEAREST 5MM FOR MINIMAL WASTAGE
- RAPID DISPATCH WITHIN 48 HOURS