

Coir Logo Mat

Fitting Guide



Indoors



Made to measure



Thickness - 17mm



PVC backing material



Mat well



Natural coir

Before fitting your Coir Logo Mat

Coir Logo Mats are provided oversized to be cut in situ to your mat well / recess.

You will need a sharp Stanley type knife, a straight edge and some chalk to do this. For a neat finish you must cut your Coir Logo Mat from the PVC backing side.

For an irregular shaped matwell / recess your Coir Logo Mat can still be trimmed following this guide.



Fitting Guide

1. Lay the mat face up over the top of the matwell / recess
2. Lift each side of the mat and run the chalk along the edge or rim of the matwell / recess coating it thoroughly with the chalk
3. Let the mat drop back onto the chalked edges to mark the backing of the mat
4. Lift the mat away from the well, turn it over and using the knife and straight edge, cut just inside the chalk mark (about 1-2mm)
5. The mat should drop straight back in to the matwell / recess
6. Extra trimming may be required